

Dept. of Environmental Health & Safety 170 Long Lane Room 107 Middletown, CT 06459 Parts Cleaner/Degreasing Unit Instructions for use November 2005



## **Summary of Operating Requirements**

- 1. Unit must have a cover that is easily operable with one hand.
- 2. Parts must be enclosed under the cover while draining. Drain cleaned parts for at least 15 seconds or until dripping stops, whichever is longer.
- 3. Close cover when parts are not being handled or when the device is not in use.
- 4. Solvent spray must be a solid fluid stream and <u>NOT</u> a fine mist or shower. Conduct all spraying within the confines of the unit at a pressure less than 10 p.s.i.
- 5. Minimize drafts across the top of the cleaning unit to greatly decrease evaporation into the atmosphere.
- 6. Do <u>NOT</u> operate the unit if there is any visible solvent leak; have the unit repaired promptly.
- 7. Waste degreasing solvent must be stored in a tightly covered container to minimize evaporation into the atmosphere to the greatest extent possible.
- 8. Maintain a monthly record of the amount of solvent added to the unit. Keep records on file for a minimum of 5 years.